

# myDIY Wardrobes

## SCREW KIT

- 1 Director screw for pre-drilled components
- 2 45mm chipboard screws for fixing top shelves to uprights to be pre-drilled
- 3 32mm chipboard screws for fixing scribes & infills to be pre-drilled
- 4 25mm chipboard screws for fixing cleats & uprights together to be pre-drilled.
- 5 1 1/2" pan head for top tracks
- 6 1" pan head for bottom tracks
- 7 1/2" pan head for fixing L brackets
- 8 1/2" counter sunk for fixing hanging rod brackets
- 9 Euro screw for runners to uprights

